


1971-2 VW TYPE 3 NOTCHBACK - SQUAREBACK
 P-JET FUEL INJECTION HARNESS

ECU CONNECTOR



2, 14, 25 = BLANK

- (A) POWER RELAY 16
- (B) POWER RELAY 24
- (D) MPS
7 8 10 15
- (E) FI3
28 6
- (F) FI4 GREY BAND
29 4
- (G) PUMP RELAY 19
- (H) TRIGGER POINTS
21 12 22
- (I) TS2 23
- (J) TS1
13 1
- (K) GROUND 28, 29
- (L) GROUND 11, 30
- (M) GROUND 26, 27
- (N) TPS
17 30 20 9

- (P) FI1
26 3
- (Q) FI2 GREY BAND
27 5
- (R) TO#50
DN STARTER 18, 33
- (S) THERMD SWITCH 32
- (T) CSV
33 32