



1971 VW TYPE 3, NOTCHBACK - SQUAREBACK  
 P-JET FUEL INJECTION HARNESS

ECU CONNECTOR



2, 14, 25 = BLANK

- (A) POWER RELAY 16
- (B) POWER RELAY 24
- (D) MPS  
7 8 10 15
- (E) FI3  
28 6
- (F) FI4 BLUE BAND  
29 4
- (G) PUMP RELAY 19
- (H) TRIGGER POINTS  
21 12 22
- (I) TS2 23
- (J) TS1  
13 1
- (K) GROUND 28, 29
- (L) GROUND 11, 30
- (M) GROUND 26, 27
- (N) TPS  
17 30 20 9

- (P) FI1  
26 3
- (Q) FI2 BLUE BAND  
27 5
- (R) TO#50  
DN STARTER 18, 33
- (S) THERMO SWITCH 32
- (T) CSV  
33 32

1971 VW TYPE 3 NOTCH BACK · SQUARE BACK